

Conference call

loop

telecoms made simple

The system can host up to 5 calls on a conference. This will also depend on how many external line you have.

Creating a conference call:

- Dial the first party and when they answer, arrow through and select “Start conference?”
- Dial the second party and when they answer, select “Conference?”
- Now party number 1, party number 2 and yourself will now be on a 3 way conference call.
- To add another party, select “Add party?”
- Dial the third party and when they answer, select “Conference?”

Loop Telecommunications Ltd
weareloop.co.uk
0330 137 3777

Opening hours:
Monday - Thursday 09:00 - 17:30
Friday 09:00 - 16:30